



Spare Parts List


605162_26.32_ECO45851

REF. 605162


February 2024 - ECO 45851

The drawings in this manual have the scope to sole purpose of illustrating the components and their assembly. The part and its relevant position. The shape of the component may be slightly different from that illustrated in the drawing


TAB. 1.0.0	Corpo assale <i>Axle housing</i>
TAB. 2.0.0	Calotte e cilindro di sterzo <i>Swivel housings and steering cylinder</i>
TAB. 3.0.0	Coppia conica <i>Bevel gear set</i>
TAB. 4.0.0	Differenziale <i>Differential</i>
TAB. 5.0.0	Doppio giunto <i>Double U-joint</i>
TAB. 6.0.0	Mozzo ruota <i>Wheel hub</i>
TAB. 7.0.0	Riduzione epicicloidale <i>Final reduction</i>




Pos.	Ref.	Q.ty	Descrizione	Description	Kit	Note
1	413749	1	Trave	Axle housing		
2	116530	2	Vite forata	Bolt		
3	116529	4	Bussola 30x21x16.5	Bush 30x21x16.5		
4	380397	1	Supporto anteriore	Front support		
5	101575	1	Boccola 115X125X42	Bush 115X125X42		
6	374423	1	Supporto posteriore	Rear support		
7	101565	1	Boccola 115x105x44	Bush 115x105x44		
8	115776	1	Ralla 145-105.5-5	Thrust washer		
9	104988	1	Sfiato M10x1	Breather M10x1		
10	128632	2	Molla tazza	Belleville washer		
11	117270	2	Bussola	Bush		
12	45166	2	Boccola	Bush		
12	45166	2	Boccola	Bush		
13	116962	2	Boccola	Bush		
14	381523	2	Anello di tenuta	Seal ring		
15	45160	2	Snodo sferico	Ball joint		
15	45160	2	Snodo sferico	Spherical bearing		
16	128631	2	Molla tazza	Belleville washer		
17	117339	1	Spina D16x40	Pin D16x40		
18	140700	1	Supporto differenziale	Differential support		
19	126064	4	Vite M16x95	Bolt M16x95		
20	94205	4	Bussola	Bush		
21	125827	12	Vite M12x1.75x33	Bolt M12x1.75x33		
22	92270	1	Tappo M22x1.5	Plug M22x1.5		
23	124591	1	Ralla	Thrust washer		




Pos.	Ref.	Q.ty	Descrizione	Description	Kit	Note
24	124592	1	Bronzina	Bush		
25	28498	1	Anello OR	O.ring		
26	123475	1	Boccola	Bush		
27	24258	2	Ingrassatore M8x1	Greaser nipple M8x1		
28	21580	1	Tappo M8x1	Plug M8x		




Pos.	Ref.	Q.ty	Descrizione	Description	Kit	Note
1	24210	4	Ingrassatore M6x1	Greaser nipple M6x1		
2	126923	16	Vite M16x38	Bolt M16x38		
3	130631	2	Perno snodo	King pin		
4	145037	1	Calotta DX	RH Swivel housing		
5	30755	8	Tappo	Plug		
6	130632	2	Perno snodo	King pin		
7	22446	2	Dado M24x1.5	Nut M24x1.5		
8	383706	2	Asta guida	Steering arm assy		
9	351504	2	Snodo sferico	Ball joint	383706	383706
10	70787	2	Dado M24x1.5	Nut M24x1.5	383706	383706
11	390287	2	Tirante	Tie rod	383706	383706
12	479857	1	Sensore	Sensor		
12	641449	1	Sensore	Sensor		
13	145038	1	Calotta SX	LH Swivel housing		
14	423978	2	Anello di tenuta	Seal ring		
15	125161	2	Bronzina	Bush		
16	124748	4	Vite M16x100	Bolt M16x100		
17	22129	4	Dado M16	Nut M16		
18	143038	4	Bussola	Bushing		
19	21231	6	Vite M20x80	Bolt M20x80		
20	28412	2	Fascetta	Clamp		
21	643142	1	Martinetto	Steering cylinder		
22	49082	1	Testata SX	LH head	643142	
23	49350	1	Stelo completo	Rod	643142	
24	49346	1	Kit guarnizioni	Seal kit	643142	




Pos.	Ref.	Q.ty	Descrizione	Description	Kit	Note
25	49347	1	Testata DX	RH head	643142	




Pos.	Ref.	Q.ty	Descrizione	Description	Kit	Note
1	66941	1	Kit coppia conica 15/37	Bevel gear set 15/37		
2	113717	1	Rondella	Washer	66941	068307
3	115054	1	Fermo ghiera	Ring nut	66941	068307
4	125829	2	Rondella	Washer	66941	068307
5	138692	1	Distanziale elastico	Collapsible spacer	66941	068307
6	64136	1	Kit Spessori	Shims Kit		
7	27351	1	Cuscinetto	Bearing		
8	27350	1	Cuscinetto	Bearing		
9	123402	1	Rondella	Washer		
10	28532	1	Anello OR	O.ring		
11	145050	1	Anello di tenuta	Oil seal ring		
12	144332	1	Flangia	Flange		
13	24789	1	Anello seeger D.34	Snap ring D.34		




Pos.	Ref.	Q.ty	Descrizione	Description	Kit	Note
1	68902	1	Kit ingranag. differenziale	Differential kit		
2	117171	4	Rondella spallamento	Thrust washer	68902	068902
3	133035	2	Perno	Shaft	68902	068902
4	133036	2	Controdisco bloc. dif.	Drive plate	68902	068902
5	128440	2	Vite M6x40	Bolt M6x40		
6	129118	2	Fermo ghiera	Lock ring		
7	125445	2	Ghiera	Ring nut		
8	27367	2	Cuscinetto	Bearing		
9	125551	10	Vite M12x1.5x90 (Atbl.)	Bolt M12x1.5x90		
10	468022	1	Scatola differenziale	Differential housing		
11	117569	2	Spina D12x40	Pin D12x40		



Pos.	Ref.	Q.ty	Descrizione	Description	Kit	Note
1	414125	2	Doppio giunto	Double joint		
2	712139	2	Forcella (lato diff.)	Fork (diff. side)	414125	
3	540754	2	Forcella Doppia	Double Fork	414125	
4	710652	4	Crociera	Spider	414125	
5	709068	2	Forcella (lato ruota)	Fork (wheel side)	414125	
6	145553	2	Ralla	Washer		
7	146945	2	Rondella	Washer		
8	147349	2	Anello arresto	Snap ring		



Pos.	Ref.	Q.ty	Descrizione	Description	Kit	Note
1	64790	2	Gruppo Mozzo Ruota	Wheel hub Kit		
2	116957	20	Prigioniero	Stud	64790	
3	149703	2	Tenuta cass. 150-180-14,5/16	Cassette seal 150-180-14,5/16	64790	
3	149703	2	Tenuta cass. 150 180 14,5/16	Cassette seal 150 180 14,5/16	64790	
4	45180	4	Cuscinetto	Bearing	64790	
5	28579	2	Anello OR	O.ring	64790	
6	125233	2	Anello	Lockring		
7	125190	16	Bussola centraggio D20	Centering bush D20		
8	119906	16	Vite M14x65	Bolt M14x65		
9	139633	2	Mozzo fermo corona	Wheel carrier		
10	125186	2	Corona epic. Z=77	Crown gear Z=77		



Pos.	Ref.	Q.ty	Descrizione	Description	Kit	Note
1	146259	2	Gruppo Treno portasatelliti	Planetary carrier assy		
2	125229	6	Vite M10x50	Bolt M10x50	146259	
3	644650	6	Ralla	Thrust washer	146259	
4	644723	6	Ingranaggio Z=31	Gear Z=31	146259	
5	28297	17	Rullini (a decine)	Bearing needles (by tens)	146259	
6	128731	6	Ralla	Thrust washer	146259	
7	20490	4	Vite M8x20	Bolt M8x20		
8	125280	3	Tappo M30x2	Plug M30x2		